



ArcSight SmartConnectors

Software Version: 8.4.3

Configuration Guide for Microsoft Forefront DB SmartConnector

Document Release Date: October 2023

Software Release Date: October 2023

Legal Notices

Open Text Corporation

275 Frank Tompa Drive, Waterloo, Ontario, Canada, N2L 0A1

Copyright Notice

Copyright 2023 Open Text.

The only warranties for products and services of Open Text and its affiliates and licensors (“Open Text”) are as may be set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. Open Text shall not be liable for technical or editorial errors or omissions contained herein. The information contained herein is subject to change without notice.

Trademark Notices

“OpenText” and other Open Text trademarks and service marks are the property of Open Text or its affiliates. All other trademarks or service marks are the property of their respective owners.

Documentation Updates

The title page of this document contains the following identifying information:

- Software Version number
- Document Release Date, which changes each time the document is updated
- Software Release Date, which indicates the release date of this version of the software

To check for recent updates or to verify that you are using the most recent edition of a document, go to:

<https://www.microfocus.com/support-and-services/documentation>

Contents

- Configuration Guide for Microsoft Forefront DB SmartConnector 4
- Product Overview 5
- Prerequisites 6
 - Configuring Logging to a SQL Server Database 6
 - Enabling SQL Server Logging in Forefront UAG 6
 - Downloading the JDBC Driver 6
- Installing the SmartConnector 8
 - Preparing to Install the SmartConnector 8
 - Installing and Configuring the SmartConnector 8
 - Adding JDBC Driver to the Connector Appliance/ArcSight Management Center11
- Device Event Mapping to ArcSight Fields13
 - Forefront UAG Mappings13
- Troubleshooting15
- Send Documentation Feedback 17

Configuration Guide for Microsoft Forefront DB SmartConnector

This guide provides information for installing the SmartConnector for Microsoft Forefront DB and configuring the device for event collection.

This guide provides a high level overview of ArcSight SmartConnectors. For supported devices and versions, see [Technical Requirements](#).

Intended Audience

This guide provides information for IT administrators who are responsible for managing the ArcSight software and its environment.

Additional Documentation

The ArcSight SmartConnector documentation library includes the following resources:

- [Technical Requirements Guide for SmartConnector](#), which provides information about operating system, appliance, browser, and other support details for SmartConnector.
- [Installation and User Guide for SmartConnectors](#), which provides detailed information about installing SmartConnectors.
- [Configuration Guides for ArcSight SmartConnectors](#), which provides information about configuring SmartConnectors to collect events from different sources.
- [Configuration Guide for SmartConnector Load Balancer](#), which provides detailed information about installing Load Balancer.

For the most recent version of this guide and other ArcSight SmartConnector documentation resources, visit the [documentation site for ArcSight SmartConnectors 8.4](#).

Contact Information

We want to hear your comments and suggestions about this book and the other documentation included with this product. You can use the comment on this topic link at the bottom of each page of the online documentation, or send an email to MFI-Documentation-Feedback@opentext.com.

For specific product issues, [contact Open Text Support for Micro Focus products](#).

Product Overview

Microsoft Forefront Unified Access Gateway (UAG), is a computer software solution that provides secure remote access to corporate networks for remote employees and business partners. It incorporates remote access technologies such as reverse proxy, virtual private network (VPN), DirectAccess and Remote Desktop Services.

Prerequisites

This section provides instructions for configuring Microsoft Forefront Unified Access Gateway to send events to the ArcSight SmartConnector.

Configuring Logging to a SQL Server Database

For complete information about configuring logging to both a local and a remote SQL Server database, see "Logging to a SQL Server in the Microsoft Forefront Unified Access Gateway" in the Microsoft TechNet Library:

<http://technet.microsoft.com/en-us/library/dd897065.aspx>

Enabling SQL Server Logging in Forefront UAG

To enable SQL Server logging, do the following:

1. Open a command line prompt and navigate to the MonitorMgr folder of the Forefront UAG installation directory. If Forefront UAG is installed in Program Files, the folder is located in the following location: Program Files\Microsoft Forefront Unified Access Gateway\utils\MonitorMgr\.
2. At the command line:
Enter `MonitorMgrUtil -setsqllogging 1`, to enable SQL Server logging.
Enter `MonitorMgrUtil -setsqllogging 0` to disable SQL Server logging.
3. On the toolbar of the Forefront UAG Management console, click the **Activate configuration** icon and then click **Activate**.
4. Restart the Forefront UAG Monitor Manager service.

Downloading the JDBC Driver

This section provides information about creating an ODBC data source. The data source configuration is performed on the machine on which you are installing the SmartConnector, and there can be only one data source per SmartConnector. This data source must match the existing configuration of the Microsoft Forefront Unified Access Gateway.

The SmartConnector installation requires JDBC driver to be present. During the installation process, you will be directed to leave the wizard and copy the JDBC driver file you downloaded to a SmartConnector folder.



Note: Different versions of the JDBC driver are required for different SQL Server database versions. The name of the jar file may be different for some JDBC driver versions. Make sure that you use the correct driver for your database version

Refer to the following information to download the correct jar file depending on the JRE version used by the SmartConnector:

- SmartConnector Version 8.3.0 uses JRE 1.8.0_312 and supports jar files from version mssql-jdbc-6.4.0.jre8.jar ([Download Microsoft JDBC Driver 6.4 for SQL Server](#)) to mssql-jdbc-9.4.0.jre8.jar ([Download Microsoft JDBC Driver 9.4.0 for SQL Server](#)).
- SmartConnector Version 7.2.1 and later use JRE 1.8 and require sqljdbc42.jar ([Download Microsoft JDBC Driver 6.0 for SQL Server](#)).
- SmartConnector Version 7.1.2 and later use JRE 1.7 and require sqljdbc41.jar ([Download Microsoft JDBC Driver 6.0 for SQL Server](#)).
- Earlier versions of SmartConnector run JRE 1.6 and require sqljdbc4.jar (available with Microsoft JDBC Driver 4.0 for SQL Server).

For more information related to the Microsoft JDBC driver, see [Microsoft Documentation](#).

Installing the SmartConnector

The following sections provide instructions for installing and configuring your selected SmartConnector.

ArcSight recommends that you do not install database connectors on the database server or any mission critical servers as this might cause performance issues.

Preparing to Install the SmartConnector

Before you install any SmartConnectors, make sure that the OpenText ArcSight products with which the connectors will communicate have already been installed correctly (such as ArcSight ESM or ArcSight Logger).

For complete product information, refer to the *Administrator's Guide to ArcSight Platform*, available on [ArcSight Documentation](#).

If you are adding a connector to the ArcSight Management Center, see the *ArcSight Management Center Administrator's Guide* available on [ArcSight Documentation](#) for instructions.

Before installing the SmartConnector, make sure that the following are available:

- Local access to the machine where the SmartConnector is to be installed
- Administrator passwords

Installing and Configuring the SmartConnector

1. Start the installation wizard.
2. Follow the instructions in the wizard to install the core software.
3. Exit the installation wizard.
4. Copy the jar file associated with the version of the driver that you downloaded earlier to `$ARCSIGHT_HOME/current/user/agent/lib`
5. To use JDBC driver with SmartConnectors to connect to Microsoft SQL Servers by using Windows authentication, copy the `sqljdbc_auth.dll` file from the JDBC driver download to the `$ARCSIGHT_HOME\jre\bin` directory.

An example of The JDBC driver download path for SQL JDBC driver is:

- For version 4.0 for 32-bit environment is `sqljdbc_4.0\enu\auth\x86\sqljdbc_auth.dll`
- For 64-bit environment, `sqljdbc_4.0\enu\auth\x64\sqljdbc_auth.dll`

To use the latest version of SQL JDBC Driver such as 9.4:

- Copy the `mssql-jdbc-9.4.0.jre8.jar` file associated with the version of the driver that you downloaded earlier to `$ARCSIGHT_HOME/current/user/agent/lib`
- Copy the `mssql-jdbc_auth-9.4.0.x64.dll` file from the JDBC driver download to the `$ARCSIGHT_HOME\jre\bin` directory.



Note: If you are upgrading the SmartConnector, you must copy the authentication file to `$ARCSIGHT_HOME\jre\bin` again after update, as the upgrade process overwrites the `$ARCSIGHT_HOME\jre\bin` directory.

6. Copy certificate and JDBC files to SmartConnector folders as follows:


- Copy the `jssecacerts` certificate that you installed during the device configuration to the SmartConnector installation folder `$ARCSIGHT_HOME/current/jre/lib/security`.



Note: You must copy this file again to the installation folder after upgrading the SmartConnector as this file gets overwritten during the upgrade process.

- Copy the `vjdbc.jar` and `commons-logging-1.1.jar` files to the SmartConnector installation folder `$ARCSIGHT_HOME/current/user/agent/lib`. These files are located in the `lib` directory that was created when you downloaded the JDBC driver and unzipped the package.

7. Browse to `$ARCSIGHT_HOME/current/bin`, then double-click `runagentsetup.bat` file to start the SmartConnector Configuration Wizard.
8. Specify the relevant Global Parameters, when prompted.
9. Select **Microsoft Forefront DB** from the Type drop-down, then click **Next**.
10. Enter the following SmartConnector Parameters:

Parameter	Description
JDBC/ODBC Driver	Select the com.microsoft.sqlserver.jdbc.SQLServerDriver driver.
URL	<p>Enter jdbc:sqlserver://<MS SQL Server Host Name or IP Address>:1433;DatabaseName=<MS SQL Server Database Name>. Replace the actual values for <MS SQL Server Host Name or IP Address> and <MS SQL Server Database Name>.</p> <p>To configure JDBC Driver and Windows Authentication, add ;integratedSecurity=true to the JDBC URL entry for the connection to your database.</p> <div>  <p>Note: The name or instance of the database configured at installation or audit time must be used. For example, jdbc:sqlserver://mysqlserver:1433;DatabaseName=my database;integratedSecurity=true</p> </div>
User	Enter the user name of the MS SQL Server DB user with appropriate database privilege.
Password	Enter the password for the database user.
Event Types	Specify the appropriate event types. The currently supported event type is 'uag' (Unified Access Gateway).



Note: Make Sure that the SmartConnector settings match the settings you entered in the data source configuration for the machine on which you are installing the SmartConnector.

- Click **Export** to export the host name data you have entered into the table into a CSV file or click **Import** to select a CSV file to import into the table rather than adding the data manually.
- Select a [destination and configure parameters](#).
- Specify a name for the connector.
- (Conditional) If you have selected **ArcSight Manager** as the destination, the certificate import window for the ArcSight Manager is displayed. Select **Import the certificate to the connector from destination**, and then click **Next**. The certificate is imported and the **Add connector Summary** window is displayed.



Note: If you select Do not import the certificate to connector from destination, the connector installation will end.

15. Select whether you want to install the connector as a service or in the standalone mode.
16. Complete the installation.
17. [Run the SmartConnector](#).

For instructions about upgrading the connector or modifying parameters, see [Installation and User Guide for SmartConnector](#).



Note: When using Windows authentication, after completing the connector installation, if running on a Windows Server, change the service account to use the Windows account that should log in to the database. The connector will use the account used to start the service, regardless of the account value setting entered in the connector setup process.

Adding JDBC Driver to the Connector Appliance/ArcSight Management Center

After downloading and extracting the JDBC driver, upload the driver into the repository and apply it to the required containers, as follows:

1. From the Connector Appliance/ArcSight Management Center, select **Setup > Repositories**.
2. Select **JDBC Drivers** from the left pane and click the **JDBC Drivers** tab.
3. Click **Upload to Repository**.
4. From the **Repository File Creation Wizard**, select **Individual Files**, then click **Next**.
5. Retain the default selection and click **Next**.
6. Click **Upload** and locate and select the .jar file you downloaded.
7. Click **Submit** to add the specified file to the repository and click **Next** to continue.
8. After adding all the files you require, click **Next**.
9. In the **Name** field, enter a descriptive name for the zip file (for example, JDBCdriver). Click **Next**.
10. Click **Done** to complete the process. The newly added file is displayed in the **Name** field under **Add Connector JDBC Driver File**.
11. To apply the driver file, select the driver .zip file and click the up arrow to invoke the **Upload Container Files** wizard. Click **Next**.

12. Select one or more containers into which you want to upload the driver, then click **Next**.
13. Click **Done** to complete the process.
14. Add the connector through the Connector Appliance/ArcSight Management Center interface. For more information, see the *Connector Appliance/ArcSight Management Center Online Help*.

Device Event Mapping to ArcSight Fields

The following section lists the mappings of ArcSight data fields to the device's specific event definitions. See the *ArcSight Console User's Guide* for more information about the ArcSight data fields.

Forefront UAG Mappings

ArcSight ESM Field	Device-Specific Field
Agent (Connector) Severity	High = Error, 3, 4; Medium = Warning, 2; Low = Information, 0, 1
Application Protocol	One of (protocol, ipsApplicationProtocol)
Bytes In	bytesrecvd
Bytes Out	bytessent
Destination Host Name	DestHost
Destination Port	DestHostPort
Destination Service Name	UagServiceName
Device Action	Action (0=Not Logged, 1=Bind, 2=Listen, 3=Get host by name, 4=Get host by address, 5=Redirect Bind, 6=Establish, 7=Terminate, 8=Denied, 9=Allowed, 10=Failed, 11=Intermediate, 12=Successful Connection, 13=Unsuccessful Connection, 14=Disconnection, 15=User Cleared Quarantine, 16=Quarantine Timeout) if UagErrorCode is '0'
Device Custom Number 1	MalwareInspectionResult
Device Custom Number 2	ClientAuthenticate
Device Custom Number 3	processingtime
Device Custom String 1	UAG_RULE
Device Custom String 2	Context Id
Device Custom String 3	Malware Inspection Result
Device Custom String 4	ClientAuthenticate (0=Not Logged, 1=YES, 2=NO)
Device Custom String 5	ipsScanResult (0=Unknown, 1=Inspected, 2=Blocked, 3=Detected)
Device Custom String 6	MalwareInspectionAction (0=No action, 1=Allowed, 2=Cleaned, 3=Blocked)
Device Event Category	UagType
Device Event Class ID	UagErrorCode
Device Host Name	servername
Device Product	'Forefront UAG'

Configuration Guide for Microsoft Forefront DB SmartConnector

Device Event Mapping to ArcSight Fields

ArcSight ESM Field	Device-Specific Field
Device Receipt Time	logTime
Device Severity	One of (UagSeverity, MalwareInspectionThreatLevel)
Device Vendor	'Microsoft'
File Type	mimetype
Message	Both (UagModuleId, FilterInfo)
Name	'Microsoft Firewall Service event'
Reason	resultcode
Request Client Application	ClientAgent
Request Method	operation
Request Protocol	One of (protocol, 'https')
Request URL	uri
Source Port	SrcPort
Source User Name	ClientUserName
Transport Protocol	transport

Troubleshooting

"What do I do when the connector can't reconnect to the MS SQL Server database?"

In some cases, connectors using MS SQL Server databases are unable to reconnect to the database after losing and reacquiring network connection. Restarting the connector will resolve this problem.

"How do I deploy SQL Server Native Client?"

When deploying an application that is dependent on SQL Server Native Client, you will need to redistribute SQL Server Native Client with your application. Unlike Microsoft Data Access Components (MDAC), which is now a component of the operating system, SQL Server Native Client is a component of SQL Server. Therefore, it is important to install SQL Server Native Client in your development environment and redistribute SQL Server Native Client with your application.

The SQL Server Native Client redistributable installation program, named sqlncli.msi, is available on the SQL Server installation media and is available as one of the SQL Server Feature Pack components on the Microsoft Download site. For more information about deploying SQL Server Native Client with your application, see "Deploying Applications with SQL Server Native Client" available from Microsoft.

"Why does my connection to SQL Server fail/hang?"

Oracle has released Java 6 update 30 (6u30) that behaves differently from JRE 6u29, causing possible database connection problems for SQL Server database connectors using JDBC connection. These connection problems can occur with JRE 1.6.0_29 (6u29) and later versions.

Microsoft recommends using JRE 6u30 (and above) instead of JRE 6u29. Apply the "SQL Server 2008 R2 Service Pack 1 Cumulative Update 6" patch to the SQL server if you are experiencing connection failures or hangs.

"Why am I receiving the message 'Login failed for user 'sqluser'. The user is not associated with a trusted SQL Server connection.'"

Only Microsoft JDBC driver v4 or later support integrated authentication. The driver also does not provide function to supply Windows authentication credentials such as user name and password. In such cases, the applications must use SQL Server Authentication. When installing the connector on a non-Windows platform, configure the Microsoft SQL Server for Mixed Mode Authentication or SQL Server Authentication.

"How can I keep the connector from becoming clogged with events after being shut down for awhile?"

If the connector is shut down for some time on an active database, a lot of events can accumulate that can clog the connector on restart. The `preservestate` parameter can be used to avoid this situation. This parameter is enabled (true) by default. Setting `preservestate` to disabled (false) in the `agent.properties` file allows the connector to skip the old events and start from real time. The `agent.properties` file is located in the `$ARCSIGHT_HOME\current\user\agent` folder. Restart the connector for your change to take effect.

"What do I do when I receive "Connector parameters did not pass the verification with error ..." message?"

You may not have the correct version of jar file. When you download the JDBC driver, the version of the jar file depends on the version of JRE the connector uses. Versions 7.2.1 and later use JRE 1.8 and require `sqljdbc42.jar`. Versions 7.1.2 and later use JRE 1.7 and require `sqljdbc41.jar`. Prior versions of the connector that run JRE 1.6 require `sqljdbc4.jar`.

Send Documentation Feedback

If you have comments about this document, you can [contact the documentation team](#) by email. If an email client is configured on this computer, click the link above and an email window opens with the following information in the subject line:

**Feedback on Configuration Guide for Microsoft Forefront DB SmartConnector
(SmartConnectors 8.4.3)**

Just add your feedback to the email and click send.

If no email client is available, copy the information above to a new message in a web mail client, and send your feedback to MFI-Documentation-Feedback@opentext.com.

We appreciate your feedback!