



ArcSight SmartConnectors

Software Version: CE 24.2

Configuration Guide for Linux Audit File SmartConnector

Document Release Date: April 2024

Software Release Date: April 2024

Legal Notices

Open Text Corporation

275 Frank Tompa Drive, Waterloo, Ontario, Canada, N2L 0A1

Copyright Notice

Copyright 2024 Open Text.

The only warranties for products and services of Open Text and its affiliates and licensors (“Open Text”) are as may be set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. Open Text shall not be liable for technical or editorial errors or omissions contained herein. The information contained herein is subject to change without notice.

Trademark Notices

“OpenText” and other Open Text trademarks and service marks are the property of Open Text or its affiliates. All other trademarks or service marks are the property of their respective owners.

Documentation Updates

The title page of this document contains the following identifying information:

- Software Version number
- Document Release Date, which changes each time the document is updated
- Software Release Date, which indicates the release date of this version of the software

To check for recent updates or to verify that you are using the most recent edition of a document, go to:

<https://www.microfocus.com/support-and-services/documentation>

Contents

- Configuration Guide for Linux Audit File SmartConnector 4
- Product Overview 4
- Configuration 6
- Preparing to Install the SmartConnector 6
- Installing and Configuring the SmartConnector by Using the Wizard 8
 - Configuring Event Merging 8
 - Device Event Mapping to ArcSight Fields 9
- Send Documentation Feedback 12

Configuration Guide for Linux Audit File SmartConnector

This guide provides information for installing the SmartConnector for Linux Audit File and configuring the device for event collection. Linux auditd is the userspace component to the Linux Auditing System that is responsible for writing audit records to the disk.

Intended Audience

This guide provides information for IT administrators who are responsible for managing the ArcSight software and its environment.

Additional Documentation

The ArcSight SmartConnector documentation library includes the following resources:

- [Technical Requirements Guide for SmartConnector](#), which provides information about operating system, appliance, browser, and other support details for SmartConnector.
- [Installation and User Guide for SmartConnectors](#), which provides detailed information about installing SmartConnectors.
- [Configuration Guides for ArcSight SmartConnectors](#), which provides information about configuring SmartConnectors to collect events from different sources.
- [Configuration Guide for SmartConnector Load Balancer](#), which provides detailed information about installing Load Balancer.

For the most recent version of this guide and other ArcSight SmartConnector documentation resources, visit the [documentation site for ArcSight SmartConnectors 8.4](#).

Contact Information

We want to hear your comments and suggestions about this book and the other documentation included with this product. You can use the comment on this topic link at the bottom of each page of the online documentation, or send an email to MFI-Documentation-Feedback@opentext.com.

For specific product issues, [contact Open Text Support for Micro Focus products](#).

Product Overview

The Linux auditd daemon is similar to network-based intrusion detection systems and host-based intrusion detection systems and can help you detect violations of your security policies. It however, does not enforce security policies. Because the audit daemon is part of the Linux kernel, it is included in most major Linux distributions by default.

Configuration

For complete information about the Linux auditd daemon, see the man pages for `auditd`, `auditd.conf`, and `auditctl`. You can access these man pages by running the `man auditd` or `man auditctl` commands, from the command line of your Linux system.

- `auditctl` is responsible for controlling the status and some basic system parameters of `auditd`. Using audit rules, `auditctl` controls which components of your system are subjected to the audit and to what extent they are audited. Audit rules can be passed to `auditd` on the `auditctl` command line as well as by composing a rule set and instructing `auditd` to process this file.
- `auditd` has built-in functions to watch access attempts to files without needing to monitor the applicable system calls. Administrators can add rules by amending the provided configuration files or at run time using the command line. The default location for the audit daemon rules in `/etc/audit/audit.rules`.

`auditd` adds events to the audit log file as they occur. By default, the system stores audit logs in `/var/log/audit/`.

Before you can start generating audit logs and processing them, configure how the daemon is started in the `/etc/sysconfig/auditd` configuration file and configure how the audit system functions once the daemon has been started in `/etc/audit/auditd.conf`.

Preparing to Install the SmartConnector

The following sections provide instructions for installing and configuring the Linux Audit File SmartConnector.



Connector Appliance or ArcSight Management Center supports mounting for Network File System (NFS) and CIFS (Windows) shares. When you install this connector on one of these devices, establish a CIFS mount on the device before adding the connector. Provide this share name during connector configuration. For more information, see **Remote File Systems** in the Connector Appliance or ArcSight Management Center Administrator's Guide.

Before you install any SmartConnectors, make sure that the OpenText ArcSight products with which the connectors will communicate have already been installed correctly (such as ArcSight ESM or ArcSight Logger).

For complete product information, refer to the *Administrator's Guide to ArcSight Platform*, available on [ArcSight Documentation](#).

If you are adding a connector to the ArcSight Management Center, see the *ArcSight Management Center Administrator's Guide* available on [ArcSight Documentation](#) for instructions.

Before installing the SmartConnector, make sure that the following are available:

- Local access to the machine where the SmartConnector is to be installed
- Administrator passwords

Installing and Configuring the SmartConnector by Using the Wizard

1. Start the installation wizard.
2. Follow the instructions in the wizard to install the core software.
3. Specify the relevant Global Parameters, when prompted.
4. From the **Type** drop-down list, select **Linux Audit File** as the type of connector, then click **Next**.
5. Enter the required SmartConnector parameters to configure the SmartConnector, then click **Next**.

Parameter	Description
Log File Name	Enter the path to and name of the log file. The default value is /var/log/audit/audit.log.

6. Select a [destination and configure parameters](#).
7. Specify a name for the connector.
8. Select whether you want to [run the connector as a service or in the standalone mode](#).
9. Complete the installation.
10. [Run the SmartConnector](#).

For instructions about upgrading the connector or modifying parameters, see [SmartConnector Installation and User Guide](#).



When using Windows authentication, after completing the connector installation, if running on a Windows Server, change the service account to use the Windows account that should log in to the database. The connector will use the account used to start the service, regardless of the account value setting entered in the connector setup process.

Configuring Event Merging

The Linux Audit system provides a way to track security-relevant information on the system. Based on pre-configured rules, Linux Audit generates log entries to record as much information as possible about the events happening on your system. These events often contains multiple sub-events that can span multiple lines. The event merging feature aggregates the related sub-events into one large event with a concatenated long

message.

To enable event merging:

1. Set up Linux Audit connector. See [Installing the SmartConnector](#).
2. Edit the `fcv.version` parameter in the `agent.properties` file (located in the `$ARCSIGHT_HOME/current/user/agent` folder) as follows: `agents [0].fcv.version=1`
3. [Run the SmartConnector](#).

Device Event Mapping to ArcSight Fields

The following section lists the mappings of ArcSight data fields to the device's specific event definitions. See the *ArcSight Console User's Guide* for more information about the ArcSight data fields.

Linux Audit Mappings to ArcSight Fields for log type PROCTITLE

ArcSight ESM Field	Device-Specific Field
Device Custom String 1	Proctitle
Device Custom String 1 Label	Proctitle

Linux Audit Mappings to ArcSight Fields

ArcSight ESM Field	Device-Specific Field
Application Protocol	proto
Destination Address	One of (daddr,laddr,dst)
Destination Mac Address	dmac
Destination Port	One of (dest, dport, lport)
Destination Process ID	One of (egid, opid)
Destination Process Name	One of (exe, comm, cmd ,ocomm)
Destination Service Name	One of (com, ocomm, grantors)
Destination User ID	One of (auid, new auid, old auid, old-auid, oid)
Destination User Name	One of (new-seuder, acct, OUID)
Destination User Privilege	new-role
Device Action	op
Device Custom Number 1	calipso_doi

Configuration Guide for Linux Audit File SmartConnector

Device Event Mapping to ArcSight Fields

ArcSight ESM Field	Device-Specific Field
Device Custom Number 2	One of (oses,ses,new ses, oldses,old-ses)
Device Custom Number 3	uid
Device Custom String 1	One of (dev, old, nsec)
Device Custom String 2	One of (key, calipso_type, new, sec)
Device Custom String 3	One of (success, res)
Device Custom String 4	One of (syscall,SYSCALL,op)
Device Custom String 5	subj
Device Custom String 6	One of (terminal, tty)
Device Event Category	All (type, res, SYSCALL)
Device Event Class ID	One of (res, type, both (type, res))
Device Host Name	node
Device Inbound Interface	inif
Device Outbound Interface	outif
Device Process Name	'auditd'
Device Product	'auditd'
Device Receipt Time	timestamp
Device Vendor	'Unix'
Device Version	One of (ver, kernel)
Event Outcome	One of (result, res, __simpleMap(success,"yes=Successful","no=Failed"))
Event Reason	One of (reason, cause)
External ID	callid
File Hash	One of (proctitle, data, cmd, fp)
File ID	One of (watch_inode, cap_fver, sw)
File Name	One of (path, name, watch, obj)
File Path	cwd One of (cwd, root_dir)
File Permission	One of (mode, perm)
File Size	ksize
Flex String 2	One of (ppid, direction)
Message	msg
Name	One of (res, SYSCALL, type, both (res, type), 'Linux Audit Message')

ArcSight ESM Field	Device-Specific Field
Old File Hash	mac
Old File ID	All of (a0,a1,a2,...), argc
Old File Name	cipher
Old File Path	cmdline
Request URL	pfs
Source Address	One of (addr,saddr,src)
Source Host Name	hostname
Source Mac Address	smac
Source Port	One of (sport, rport)
Source Process ID	One of (pid, Spid, spid)
Source User ID	One of (saud, uid, oauid,AUID)
Source User Name	One of (user, old-seuser, EUID,OAUID)
Source User Privileges	One of (old-role, EGID)



Note: The connector will not receive events if MySQL JDBC driver 5.1.38 was used when you configured it. To fix this issue, apply MySQL JDBC driver 5.0.8.

Send Documentation Feedback

If you have comments about this document, you can [contact the documentation team](#) by email. If an email client is configured on this computer, click the link above and an email window opens with the following information in the subject line:

Feedback on Configuration Guide for Linux Audit File SmartConnector (SmartConnectors CE 24.2)

Just add your feedback to the email and click send.

If no email client is available, copy the information above to a new message in a web mail client, and send your feedback to MFI-Documentation-Feedback@opentext.com.

We appreciate your feedback!